

2 WIRES PRESSURE TRANSMITTER

Model : TR-PS2W-xxBAR *ISO-9001, CE, IEC1010*



FEATURES

Model : TR-PS2W-xxBAR

- * Range : 2, 5, 10, 20, 50, 100, 400 BAR.
- * Output : 4 to 20 mA DC.
 - 4 mA = 0 pressure
 - 20 mA = full scale pressure
- * 2 wires, both for signal and power supply.
- * Precision ceramic type pressure sensor.
- * External zero and span adjustment.
- * Allow high cable load resistance, transmitter install far away from the controller/incator.
- * Protection for the reverse wires connecting.
- * TR-PS2W can cooperate the " 4-20 mA Controller/Alarm/Indicator " CT-2002-MA, then become a pressure controller and the indicating system. The user can control and monitor the pressure value from far away.



LUTRON ELECTRONIC

The Art of Measurement

2 WIRES PRESSURE TRANSMITTER

Model : TR-PS2W-xxBAR

SPECIFICATIONS		
<i>Measuring range/ Model</i>	<i>Measuring Range</i>	<i>Model</i>
	2 BAR (29 PSI)	PS2WMA-2BAR
	5 BAR (72.5 PSI)	PS2WMA-5BAR
	10 BAR (145 PSI)	PS2WMA-10BAR
	20 BAR (290 PSI)	PS2WMA-20BAR
	50 BAR (725 PSI)	PS2WMA-50BAR
	100 BAR (1450 PSI)	PS2WMA-100BAR
	400 BAR (5800 PSI)	PS2WMA-400BAR
<i>Output</i>	4 - 20 mA 4 mA = 0 BAR 20 mA = Full scale pressure	
<i>Supply voltage</i>	DC 9V to 30 V <i>* Protected against reverse polarity</i>	
<i>Wire numbers</i>	2 wires, biot for signal and power supply.	
<i>Port connector</i>	PS 1/4", 19 teeth per inch.	
<i>Span and Zero adjustment</i>	Span and Zero can be adjustment by multi turns VR.	
<i>Span</i>	± 1 % F.S. <i>* Within 10 °C to 40 °C.</i>	
<i>Zero</i>	± 2 % F.S. <i>* Within 10 °C to 40 °C.</i>	
<i>Load impedance requirement</i>	Load up to 500 ohms.	
<i>Operating Temperature</i>	-20 °C to 80 °C (-4 °F to 176 °F).	
<i>Operating Humidity</i>	Less than 80% RH.	
<i>Size</i>	30 mm dia. x 85 mm (1.2 inch dia. x 3.3 inch).	
<i>Weight</i>	160 g.	
<i>Output connector</i>	Socket	
<i>Wire Connection</i>	2 wires : Connection 1 : Power + and signal Connection 2 : Power -	

APPLICATIONS
<ul style="list-style-type: none"> * Measure Pneumatic Pressures. * Measure Automobile Engine Vacuum Pressures. * Pressure for Super Heat Measurements * Hydraulic Servo controls * Refrigeration * Air conditioning * Food Processing