all in one, bar graph LED + LCD

MOISTURE METER

Model: MS-7003 *ISO-9001, CE, IEC1010*







The Art of Measurement

Concrete/Wood, Red LED bar graph + LCD display

MOISTURE METER

Model: MS-7003

FEATURES

Designed to check the moisture level of wood, concrete,		
and other non-wood material.		
6 % to 40 % moisture range on wood.		
0 to 100% relative moisture value for Concrete and		
other non-wood material.		
* Red LED bar graph indicator and LCD digital display.		
All in one, meter build in the test pins.		
Optional separate probe, available for remote		
measurement.		
Microprocessor circuit assures maximum possible		
accuracy, provides special functions and features.		
Records Maximum & Minimum reading with recall.		
Data hold function to freeze the desired value on display.		
Heavy duty & compact housing case, designed for easy		
carry out & operation.		
Built-in low battery indicator.		
With auto power shut off function to prolong the battery		
battery life.		

SPECIFICATIONS

Applications	Designed to check the moisture level of
	wood, concrete and other non-wood
	material.
Principal	Used the 2 pins electrode to measure the
	conductive ability of the species, then
	converter to the reading of % " Moisture
	of Content ".
Circuit	Custom one-chip of microprocessor LSI
	circuit.
Display	LCD size : 51 mm x 37 mm
	Digit size: 16 mm (0.62 ")

_	<u>, </u>
Material/	Material 1 :
Range	0 to 100% relative moisture value for
	Concrete. and other non-wood material.
	Material 2 :
	6 % to 40 % moisture range on wood.
Resolution	0.1 %.
Accuracy	± (5% + 5d)
	@ 23±5 ℃
	@ Material 1 : 13 % to 100%
	@ Material 2 : 6 % to 40%
Probe	2 pins moisture electrode.
Data Hold	By push button on front panel.
Memory Recall	Records Maximum & Minimum reading
	value.
Sampling Time	Approx. 0.8 second.
Operating	0 to 50 $^{\circ}\mathrm{C}$ (32 to 122 $^{\circ}\mathrm{F}$).
Temp./Humidity	Less than 80 %RH.
Power Supply	Alkaline 006P, MN1604 (PP3) DC 9V
	battery.
Power Current	Approx. DC 16 mA.
Weight	251 g/0.55 LB.
Dimension	216.5 x 68.5 x 29.7 mm
	(8.4 x 2.7 x 1.2 inch).
Accessories	Instruction manual1 PC.
Included	Extra contact pins1 Set.
Optional	Separate Probe, MP-31
Accessories	Hard Carrying Case, CA-06
	Soft Carrying Case, CA-05A

^{*} Appearance and specifications listed in this brochure are subject to change without notice.